

How do I know the identity of the SMTP SERVER, THE USERNAME AND THE PASSWORD?

SMTP server is a computer server that sends and receives your email for you. Please consult your email provider or if you use Microsoft Outlook, you can find your SMTP server at tool-Email accounts-view or change email account.

1. You can check with your internet service provider for SMTP server address. For example, AOL's SMTP is "smtp.aol.com", according unofficial web sources.
2. For most company mail, you can get the SMTP server from your IT personal. SMTP Username could be your email address for example: ipcam@aol.com Or could be just your email address without SMTP server, such as ipcam. If one username does not work, please try the other one. The setting is different between different SMTP server. SMTP Password is your password to your email account.

Please refer to the picture below.

- a) AOL or other SMTP server.

The screenshot shows a web interface for a 'Wireless Day & Night IP Camera'. The main heading is 'Seeing the video from anywhere'. The interface is divided into a left sidebar and a main content area. The sidebar has a blue background and contains a navigation menu with the following items: Information, Network, Video, Schedule, Email/ftp Alarm (highlighted), NAS Settings, Scheduling, and Admin. Below the menu is a 'Language' dropdown set to 'English'. The main content area has a green header for 'Email/FTP Alarm Settings'. Below this header are several settings rows:

Email/FTP Trigger	<input checked="" type="radio"/> Motion <input type="radio"/> Schedule <input type="radio"/> Disable
Motion sensitivity	5(medium) ▼
<input checked="" type="checkbox"/> Send Email message <input type="checkbox"/> Send FTP message	
Email recipient	ipcam@aol.com
SMTP server	smtp.aol.com port 25
SMTP Username	ipcam@aol.com (name@server)
SMTP Password	•••••
FTP Server	
Username	
Password	
Remote folder	

At the bottom of the settings area are two buttons: 'Save & Apply' and 'SMTP server test'.

OR

b) Siriesoft's SMTP server.

Seeing the video from anywhere

Wireless Day&night IP Camera

Information
Network
Video
Schedule
Email/ftp Alarm
NAS Settings
Scheduling
Admin

Language: English

Email/FTP Alarm Settings

Email/FTP Trigger: Motion Schedule Disable

Motion sensitivity: 5(medium)

Send Email message Send FTP message

Email recipient: [Your Email Address]

SMTP server: mail.siriesoft.com port 25

SMTP Username: ipcam2@siriesoft.com (name@server)

SMTP Password: 123456789

FTP Server: []

Username: []

Password: []

Remote folder: []

Save & Apply SMTP server test

Example: amy@hotmail.com / amy@yahoo.com / amy@gmail.com / amy@siriesoft.com

You may test the connection by “SMTP server test” button.

SMTP testing status

Status Test success!

If testing failed, please check the settings.

OK

How do I know the identity of the FTP server, it's username & password?

FTP is a way to transfer data from one computer to the other in the internet. There are many ways to transfer data, like HTTP, FTP, RSTP... ect. FTP is one of the popular ways.

Many companies or schools have a FTP server to save and share documents and data.

You can consult your IT personal for FTP matter. Your IT personal should be able to set up an FTP for you, also the username, password, and remote folder.